

Emergency Response Plan

- Isolate the contaminated area for all personnel to ensure the safety of the public and the workers.
- Contact the relevant authorities and record the incident.
- All employees transporting asbestos have training and handling of asbestos. Follow procedure of training and contact asbestos supervisor to notify and advise of the situation. Supervisor will be within 20 minutes of asbestos removal and transport at all times. Control the contamination to ensure there is no spread/exposure using appropriate safety supplies and equipment for asbestos handling. Locate first aid and response equipment in the left side of the truck, which is clearly marked.
- Removal of contaminated material in the incident will be treated as a high-risk task and Safety Work Methods will be followed accordingly. Prevent contamination of waterways by the utilisation of sandbags/sediment traps.
- Inspect location of contaminated material to ensure it is 100% safe.