

SPILL RESPONSE PLAN

KLEEN YARDS WASTE SERVICE

Step 1. Be safe. Put on appropriate safety gear. Avoid the spill if dangerous.

Step 2. Stop the source: Locate the source of the spill. Turn off equipment and attempt to plug any leaks.

Step 3. Protect stormwater: Contain the spill with berms (socks) and cover nearby stormwater drains with mats.

Step 4. Notify: Tell your pollution prevention point person, supervisor, and notify any environmental or health agencies.

- Contact Hazmat at Katherine Hospital Manager – (08) 89739211
- Contact Fire Department at Katherine NTPFE – (08) 89738014
- Contact Point-person at KLEEN YARDS
- Contact Daniel Kelly – 0474490368

Step 5. Clean up: Use spill absorbents to clean up small spills. Large spills can be pumped into containers. Hazardous spills should be handled by the appropriate spill respondents.

Step 6. Dispose responsibly: Contaminated materials should be disposed of safely. Never put hazardous waste (oily rags, absorbents, solvents, etc) into normal waste collection bins. Dry spills may have useable, uncontaminated materials that can be put into storage containers.

Step 7. Restock and review: Replace all used clean-up materials with new, unused products. Assess why the spill occurred and how to prevent future spills.

- For clean-up material replacement, contact BOC Gas and Gear at MR Engineering, Katherine (08) 89710066.